




Top Gusset



Middle Gusset




Bottom Gusset



1to28, B1toB4 = Uniaxial Strain Gauge

29to44 = Triaxial Strain Gauge



B1 Group  
(same rule for  
B2 B3 B4)

B1:45 to 50, B2:51 to 56, B3:57 to 62, B4:63 to 68