

B1 Group
(same rule for
B2 B3 B4)

1to28,B1toB4 - Uniaxial Strain Gauge

29to44 Triaxial Strain Gauge

B1:45to50,B2:51to56,B3:57to62,B4:63to68